




SERIES 8000 MULLING INSTRUCTIONS

WESTERNAO.COM



SCAN
TO PLAY
VIDEO



This guide provides step-by-step instructions for mulling and installation of mulled combination products of the 8000 Series Collection. Sealants used should be compatible with the building envelope's waterproofing membrane. Drip caps should be ordered when the window is ordered. Application of building components such as flashing and WRB may vary. Refer to those manufacturers' instructions for incorporation and installation of their products. Western is not responsible for proper integration of its products into the structure for weather management. See current versions of AAMA 2400 and ASTM E2112 for pre-installation and installation details.

Contact us:

2200 E. Riverview Dr., Phoenix, AZ 85034

877-268-1300

WesternAO.com



CAUTION

We recommend all Western Architectural Openings products be installed by experienced professionals



TABLE OF CONTENTS

1	Important Safety Information	04
2	Material and Tool List.....	08
3	Parts List.....	09
4	Prepare Rough Opening	10
5	Mulling Instructions	11
6	Installation	15
8	Finishing.....	17



NOTE

Unless specifically indicated on the Figure as "Interior View". All figures in this installation guide are detailed from window exterior.



IMPORTANT SAFETY INFORMATION



WARNING

Risk of injury, potentially serious, if warning is not heeded



CAUTION

Risk of injury if precaution isn't taken



NOTE

Additional information is important to the installation

Read instructions, front to back, before beginning installation.

Product Storage and Transports

Product should be stored in a dry location protected from the elements. Wet packaging can cause damage to product finishes. If the packaging becomes wet, immediately replace it with dry packaging. Product should be stored and transported upside down. To avoid damage, do not drop or drag product from the delivery truck. Care is required in handling, transport and storing products to avoid compromising the integrity of components and product performance. Failure of care may limit warranty remedies.

Removal of Old Fenestration Products

Ensure that old fenestration products are removed and properly disposed. You may be able to recycle or donate removed glass and frames. For more information, check with your local recycling agency, the Fenestration & Glazing Industry Alliance (FGIA, f/k/a American Architectural Manufacturers Association, the U.S. Environmental Protection Agency, or the Building Materials Reuse Association to locate a nearby company or organization that accepts used windows and doors. To donate removed products, contact local nonprofits in need of building supplies, such as Habitat for Humanity.



WARNING

Homes and condominiums built before 1978 may have lead-based paint, which can pose serious health hazards during removal. Information and instruction regarding proper management of lead-based paint is available at www.epa.gov/lead.



IMPORTANT SAFETY INFORMATION

Safety and Handling

Installation of the product is not a “do-it-yourself” project. The product should be installed only by experienced, qualified, and where required, licensed installation professionals.

- Read and fully understand ALL manufacturer’s instructions prior to beginning the installation. Failure to follow applicable installation instructions and industry standards, such as AAMA 2400 and ASTM E2112, may affect coverage under the applicable Western Architectural Openings express limited warranty.
- This is a finished product that must be protected before, during and after installation to prevent damage to the glass, frame, finish and hardware. All component parts should be stored in a dry location that is protected from the elements.
- Before proceeding with installation, inspect the product and component parts and confirm that there is no damage or condition that will affect appearance or performance. Damaged or missing parts should be reported to your dealer immediately.
- Use caution when working at elevated heights including but not limited to ladders and scaffolding.
- It is the responsibility of the installation contractor to consult and establish appropriate safety and health practices and determine the applicability of regulatory limitations prior to commencing installation.
- Do not work alone and use safe lifting techniques. Two or more people may be required to lift. Use a reasonable amount of people with enough strength to lift, carry and install to avoid injury and/or damage to the Product. Consult product order information for measurements and weight.
- Use caution when handling glass. Broken or cracked glass can cause serious injury.
- Wear protective gear (safety glasses, gloves, ear protection, etc...).
- Operate hand and power tools safely and follow the manufacturer’s operating instructions.
- Job site and worker protections are recommended and may be required.



IMPORTANT SAFETY INFORMATION

Components

The components supplied will vary depending on the configuration you are installing. Before proceeding with the installation, inspect the components to become familiar with them. Confirm all parts and components have been ordered and delivered.

Confirm there is no damage that will affect the appearance or performance of the installed product. Damaged or missing parts should be reported to your dealer within 48 hours of delivery.



NOTE

Some windows will be shipped knocked down, in this case glass will need to be field glazed. Please consult a glazing contractor.

Installation Preparation

Prior to installation, it is important that you carefully review and understand the installation instructions and any drawings supplied. Western Architectural Openings fenestration products should be installed only by experienced and qualified installation professionals. Failure to follow these instructions and industry standards may result in poor performance, including but not limited to, operation, security, and weatherproofing failures, and may void Western Window Systems expressed limited warranties.

This is a finished product that must be protected before, during, and after installation to prevent damage.

Failure to follow these recommendations, local requirements, and good building practices may result in poor performance including, but not limited to, operation, security and weatherproofing failures and may void coverage under the applicable Western Window Systems' express limited warranty. Provide a copy of these recommendations and the applicable Western Window Systems' express limited warranty to the owner before installing. Western Window Systems does not permit adoption of its installation recommendations into the contracts of others without its prior, written consent.

Please contact Western Window Systems at 1-877-268-1300 for clarification.



NOTE

NOTE: The rough opening must be waterproofed in accordance with AAMA Installation Masters standards, as well as flashing and sealant manufacturer instructions, and must meet local building codes. Applicable industry standards AAMA 2400, AAMA Installation Masters™ ASTM E 2112, FMA/AAMA/WDMA 300-12 should be consulted.



REQUIREMENTS FOR A SUCCESSFUL INSTALL

Rough Opening

Ensure that the sill is flat and level.

Ensure that the entire opening is square and plumb. These instructions do not address all potential installation conditions and are minimum requirements. Building codes and industry standards may provide further details not included here.



MANPOWER

Multiple people should be used to install these systems. Consult product weight and measurements in order documents or contact WAO.



PROTECTION FROM WIND AND RAIN

Systems should be installed with overhead protection from wind and rain to prevent potential damage from water. We recommend that a professional waterproofing consultant be used to ensure proper steps are taken to reduce the potential for damage.



INSTALLING IN EXISTING STRUCTURES

System installation may disturb surfaces and paint in existing structures. Specific notice and work site precautions may be required. Additional information is available at www.epa.gov/lead. Comply with all applicable federal, state and local requirements.



INSTALLING IN EXISTING STRUCTURES

Special disposal considerations may be necessary for materials used during installation. Materials removed from an existing structure may also have their own disposal or recycling requirements. Comply with all applicable federal, state and local requirements.



MATERIAL AND TOOL LIST

Materials and tools indicated below are general suggestions. Additional or different items may be required depending on the type of install and regional code requirements.

Materials Required:

- ☐ Non-compressible shims.
- ☐ Fasteners for Wood Frame Installation provided
 - Type and number as required by code.
 - At minimum fastener type should be sufficient to properly affix the frame.
- ☐ Flexible membrane for sill pan flashing system.
- ☐ High quality compatible exterior grade sealant.
- ☐ Seal tape for the weather resistant barrier.
- ☐ Self-adhering flashing
 - In a width required by code but no less than 4".
 - AAMA 711 compliant flexible butyl tape flashing or equivalent is recommended.
- ☐ Backer rod.
- ☐ 2" Chip brush for spreading Liquid Applied Flashing.
- ☐ Joint knife, trowel, or spatula for applying Liquid Applied Flashing.
- ☐ Low-expansive, low-pressure foam or batt type insulation.
- ☐ DRILL BIT size required: #7 OR 13/64".

Other Material may be required for flashing and WRB integration. Consult other material manufacturer instructions.

Tool Checklist:





INSTALL OPTIONS

Verify the window is the correct size and the rough opening is sized correctly to for the unit(s) to be installed. If you are mulling two or more windows, refer to the mulling instructions found at the end of this instruction manual.

There are three install options for the 8000 Series, as seen below. Verify you are using the correct instructions based on your configuration of window.



Door to Fixed Window



Casement Window to Casement Window



Fixed Window to Fixed Window



PREPARE ROUGH OPENING

Wood Frame Construction

- Width of the prepared rough opening should be at least $\frac{1}{2}$ " more than unit width. Height of rough opening should be $\frac{1}{2}$ " more than unit height. Account for thickness of flashing material.
- Check sill plate for level. Sill must be level. Shim if needed.
- Check rough opening for plumb and level. If rough opening is not plumb or level, correct as needed.
- Check rough opening for square by measuring diagonally across, upper left to lower right and upper right to lower left corner. If measurements are within $\frac{1}{8}$ ", opening is square. If rough opening is not square, correct as needed.
- Cut house wrap along sill and head of rough opening.
- Cut house wrap vertically in center of rough opening from head to sill.
- Fold house wrap around to inside, trim excess and staple.
- Cut top corners of house wrap on 45° angles the width of head flashing. For arch top and Springline™ units, cut top corners on 45° angle for 8" to 10" then cut straight up until the cuts equal the width of the head flashing above the unit. See drawing.
- Fold flap up and temporarily tape in position.
- Apply sill flashing to rough opening sill. Keep sill flashing 6" above sill at sides and 2" to 3" onto house wrap around exterior.
- Secure corners of sill flashing by stapling, taping or nailing in position. Stapling shown in drawing.





MULLING INSTRUCTIONS



Fig 1. Begin by locating the side where you wish to mull together with another door or window.




Fig 2. Next, locate the Starting End. The Starting End, is the end of the unit where the mulling process will begin, as decided by the installer.




Fig 3. Lay a bead of sealant on each of the smaller top legs of the mull jamb.




Fig 4. Lay a bead across the entire jamb.



MULLING INSTRUCTIONS




Fig 5. After the sealant is applied, attach the Mull Clip.

With the snapping leg pointed towards the outside edge of the frame, push the snapping feature into position.




Fig 6. Press the flush side of the mull clip down so the clip fits flush into the mulling cavity.

Continue to press the flush side of the mull clip along the entire mull clip until it sits flush along the entire jamb.




Fig 7. Repeat the previous steps to the other mulling cavity. Assure you orient the snapping feature of the mull clip the other direction.

Both snapping features should fall to the outside edges of the frame, while the flush side points towards the thermal.



Fig 8. Next, Use the same methods in the previous steps to prepare the jamb of the unit that will mull to the first unit.

No need to install a mull kit on the second unit.



Mulling can be applied to a Door or Window



MULLING INSTRUCTIONS




Fig 9. After prepping the jamb, align the two units so that the mull faces are close to one another and gently clamp the interior and exterior of the “starting end”.

Increase the pressure of the clamp on the extrusion until the extrusions flush with one another. You should hear an initial snap of the mull clip into place.




Fig 10. Increase the pressure of the clamp on the opposite side until we have the “starting end” flush on both the interior and exterior. If the extrusion is not flushing out properly the leg might be deflecting into the wrong position.



MULLING INSTRUCTIONS




Fig 11. Loosening the clamp and using a tool to push the snapping leg into the extrusion may allow this to come together easier.

During more difficult situations such as fixed sash sets with beveled stops, you may need to remove the glass stops to provide a clamping surface.




Fig 12. Remove the lower clamp on the strong side and reuse it slightly above the clamp above it.

Continue to move the clamps up the strong side until the jambs are fully joined on the strong side.




Fig 13. Leave the last clamp on the strong side and move the remaining clamp back to the starting end of the strong side.

Using the same alternating clamp technique from the previous steps, zip the opposite side jambs together.



Fig 14. Once both the strong and opposite sides of the jamb have been fully joined, we recommend keeping a clamp at the top, bottom and middle of both the strong and opposite side until the silicone cures.



MULLING INSTRUCTIONS - INSTALLATION




Fig 1. When installing your Muller Windows or doors, you will need to install the Drip Cap and Mull Bridge.

See the Window or Door Install Video for more information regarding installation.




Fig 2. First, lay a steady bead of sealant along the entire length of all nail fins on the head.



Fig 3. After applying sealant everywhere that will contact the drip cap, place the drip cap on top of the frame, and make sure it's flush with the nail fin and the frame.




Fig 4. Once the drip cap is in place, apply sealant to the underside, as well as both outer edges. Do not install over a mull bridge.

Proceed with final waterproofing membrane applied over the nail fin. Ensure a complete seal.



MULLING INSTRUCTIONS - INSTALLATION




Fig 5. Once the Drip Cap is Installed, locate the bottom middle of the assembly.

Apply sealant to the bottom of the assembly. There should be a good amount of sealant where the mull bridge is placed for a proper seal.




Fig 6. Next, install the Mull Bridge. Orient and press the mull bridge into place between and in front of the nail fins.



Fig 7. Ensure a complete Seal.



FINISHING INSTRUCTIONS

FINISHING

- Apply interior casing to complete installation.
- Finish all hidden wood surfaces
- Do not overload brush with stain/paint when finishing.
- Finish may wick between glass stop/grille on glass.
- Read and follow “Care, Finish, and Maintenance Guide”.
- Read and follow finishing product instructions and warnings on finishing materials

MAINTENANCE

- Do not apply any type of film to insulated glass.
- Thermal stress and glass damage can result. Shading devices (insulated covers, shutters, etc.) may also cause thermal stress and condensation damage.
- For more information regarding Maintenance contact your local Western Architectural Openings or visit www.westernAO.com

CLEANING

- Clean glass using liquid glass cleaner.
- Clean exterior frame, sash and insect screens using mild detergent and water with a soft cloth or brush.
- For hard to clean areas use a nonabrasive cleaner, alcohol-and-water or ammonia-and-water. For more information regarding Cleaning visit www.westernAO.com.



CAUTION Acid solutions used for cleaning masonry or concrete will damage glass, fasteners, hardware, and metal flashing. Protect unit and follow cleaning product instructions carefully. If acid contacts unit, wash all surfaces with water immediately.



CAUTION Abrasive cleaners will damage glass surface.



CAUTION Metal razor blades can damage glass surface and exterior coating.



SERIES 8000

MULLING INSTRUCTIONS

Upon completion of installation, ensure all connections are tight and secure in accordance with the installation manual and AAMA Installation Masters standards. For more information, give us a call or visit us online.

We recommend all Western Architectural Openings products be installed by experienced professionals.

Western Architectural Openings
2200 E. Riverview Dr., Phoenix, AZ 85034
877-268-1300
WesternAO.com